### **Operating Instruction & Parts Manual**

#### 32V127 and 32V128

Please read and save these instructions. Read carefully before attempting to assemble, install, operate or maintain the product described. Protect yourself and others by observing all safety information. Failure to comply with instructions could result in personal injury and/or property damage! Retain instructions for future reference.

### Dayton® Direct Drive Tank Mixer

#### Description

Mixers are designed for economical mixing of small tanks and open head drums. The mixer can be easily mounted and the shaft angle can be conveniently moved from one container to another.

#### Unpacking

When unpacking the mixer, check for both damage that may have occurred during transit and missing parts.

**General Safety Information READ AND FOLLOW THE SAFETY INSTRUCTIONS!** 



These mixers are

functions. Please follow all instructions to insure safe and proper use.

- (1) Be certain that all mounting hardware, including the coupling and propeller setscrews, are properly (3) Insert mounting plate tightened prior to operation.
- (2) Clamp the rim securely. Be certain bolt. Tighten the hex nut so round end of mixer shaft. propeller is not touching side or bottom of tank.
- (3) Do not attempt to adjust the mixer when it is in operation. This could result in personal injury or damage to the tank and mixer.

(4) Always wear safety equipment, including eye protection, when observing the mixer performance or when adding materials to a tank while the mixer is in operation.

#### Assembly Instructions

- intended for specific (1) Bolt motor to clamp assembly using enclosed hardware.
  - (2) Place pivot bolt through coupling, with the two clamp body so that head bolt inserts in hex nut. bar through hole in pivot that it binds the motor mounting plate to prevent shaft into coupling and movement.
  - (4) Attach coupling to motor shaft using setscrews.



Note: The end of the setscrews spaced closely together, should be attached to the motor. (5) Attach propeller to (6) Insert the flat end of tighten setscrews. (7) Recheck all hardware to ensure that they are

properly tightened. (8) Attach to tank using hand wheel on clamp.


Form 5S7185

Printed in China 09667 Version 0 09/12



# Dayton<sup>®</sup> Direct Drive Tank Mixer

# **Outline Drawing**




# **Specifications**

Model	НР	Motor Type	Air Pressure (PSI)	Consumption (CFM)	Speed (RPM)	Shaft Dia. (In.)	Shaft Length (In.)	Propeller Dia. (In.)	Air Motor in/out thread	Dimension (In.)	
										Α	В
32V127	1	4AM-H-127	70	16	500-2000	5/8	36	6	NPT 1/4	40	37 3/4
Model	НР	Motor Type	Air Pressure (PSI)	Consumption (CFM)	Speed (RPM)	Shaft Dia. (In.)	Shaft Length (In.)	Propeller Dia. (In.)	Air Motor in/out thread		nension n.) B
32V128	2	6AM-H-158	70	20	500-2000	3/4	36	8	NPT 1/2	45	37 3/4


### Model 32V127 and 32V128

## 32v127 Part Exploded View Illustration



# Dayton® Direct Drive Tank Mixer

# 32v128 Part Exploded View Illustration



### Model 32V127 and 32V128

## Part list

		Model					
Ref		32V127		32V128			
No.	Description	Part	Quantity	Part	Quantity		
		Number		Number			
1	Propeller	*	1	*	1		
2	Square-head Setscrews (5/16"-18NUC x 16)	**	2	**	2		
3	Shaft (5/8" x 36") (32V127)	*	4	*	4		
	(3/4" x 36") (32V128)	^	1	^	1		
4	Connection Socket	*	1	*	1		
5	Setscrews (1/4"-20UNC x 8)	**	4	**	4		
6	Loose Joint Nipple	**	3	**	2		
7	Needle Valve	**	1	**	1		
8	Angle Fitting	**	3	**	4		
9	Long Female Connector	*	1	*	1		
10	M2 External Connection	**	1	**	1		
11	Muffler	**	1	*	1		
12	Hexagon Bolt	**	4	**	4		
13	Air Motor	*	1	*	1		
14	Motor Connection	*	1	*	1		
15	Hexagon Bolt (M16 x 100)	**	1	**	1		
16	Washer	**	4	**	4		
17	Nut	**	4	**	4		
18	Slip Stopper	*	2	*	2		
19	Fixed Mount	*	1	*	1		
20	Cushion Cover	*	1	*	1		
21	Spring Washer 16	**	1	**	1		
22	Hand Wheel A	*	1	*	1		
23	Quarter Bend A1	**	1				

<sup>(\*)</sup> Not available as repair part (\*\*) Common Hardware, not offered as a replacement part

### Dayton<sup>®</sup> Direct Drive Tank Mixer

#### LIMITED WARRANTY

DAYTON ONE-YEAR LIMITED WARRANTY. DAYTON® TANK MIXERS, MODELS COVERED IN THIS MANUAL, ARE WARRANTED BY DAYTON ELECTRIC MFG. CO. (DAYTON) TO THE ORIGINAL USER AGAINST DEFECTS IN WORKMANSHIP OR MATERIALS UNDER NORMAL USE FOR ONE YEAR AFTER DATE OF PURCHASE. ANY PART WHICH IS DETERMINED TO BE DEFECTIVE IN MATERIAL OR WORKMANSHIP AND RETURNED TO AN AUTHORIZED SERVICE LOCATION, AS DAYTON DESIGNATES, SHIPPING COSTS PREPAID, WILL BE, AS THE EXCLUSIVE REMEDY, REPAIRED OR REPLACED AT DAYTON'S OPTION. FOR LIMITED WARRANTY CLAIM PROCEDURES, SEE "PROMPT DISPOSITION" BELOW. THIS LIMITED WARRANTY GIVES PURCHASERS SPECIFIC LEGAL RIGHTS WHICH VARY FROM JURISDICTION TO JURISDICTION.

LIMITATION OF LIABILITY. TO THE EXTENT ALLOWABLE UNDER APPLICABLE LAW, DAYTON'S LIABILITY FOR CONSEQUENTIAL AND INCIDENTAL DAMAGES IS EXPRESSLY DISCLAIMED. DAYTON'S LIABILITY IN ALL EVENTS IS LIMITED TO AND SHALL NOT EXCEED THE PURCHASE PRICE PAID.

WARRANTY DISCLAIMER. A DILIGENT EFFORT HAS BEEN MADE TO PROVIDE PRODUCT INFORMATION AND ILLUSTRATE THE PRODUCTS IN THIS LITERATURE ACCURATELY; HOWEVER, SUCH INFORMATION AND ILLUSTRATIONS ARE FOR THE SOLE PURPOSE OF IDENTIFICATION, AND DO NOT EXPRESS OR IMPLY A WARRANTY THAT THE PRODUCTS ARE MERCHANTABLE, OR FIT FOR A PARTICULAR PURPOSE, OR THAT THE PRODUCTS WILL NECESSARILY CONFORM TO THE ILLUSTRATIONS OR DESCRIPTIONS. EXCEPT AS PROVIDED BELOW, NO WARRANTY OR AFFIRMATION OF FACT, EXPRESSED OR IMPLIED, OTHER THAN AS STATED IN THE "LIMITED WARRANTY" ABOVE IS MADE OR AUTHORIZED BY DAYTON.

**Technical Advice and Recommendations, Disclaimer.** Notwithstanding any past practice or dealings or trade custom, sales shall not include the furnishing of technical advice or assistance or system design. Dayton assumes no obligations or liability on account of any unauthorized recommendations, opinions or advice as to the choice, installation or use of products.

Product Suitability. Many jurisdictions have codes and regulations governing sales, construction, installation, and/or use of products for certain purposes, which may vary from those in neighboring areas. While attempts are made to assure that Dayton products comply with such codes, Dayton cannot guarantee compliance, and cannot be responsible for how the product is installed or used. Before purchase and use of a product, review the product applications, and all applicable national and local codes and regulations, and be sure that the product, installation, and use will comply with them. Certain aspects of disclaimers are not applicable to consumer products; e.g., (a) some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you; (b) also, some jurisdictions do not allow a limitation on how long an implied warranty lasts, consequently the above limitation may not apply to you; and (c) by law, during the period of this Limited Warranty, any implied warranties of implied merchantability or fitness for a particular purpose applicable to consumer products purchased by consumers, may not be excluded or otherwise disclaimed.

**Prompt Disposition**. A good faith effort will be made for prompt correction or other adjustment with respect to any product which proves to be defective within limited warranty. For any product believed to be defective within limited warranty, first write or call dealer from whom the product was purchased. Dealer will give additional directions. If unable to resolve satisfactorily, write to Dayton at address below, giving dealer's name, address, date, and number of dealer's invoice, and describing the nature of the defect. Title and risk of loss pass to buyer on delivery to common carrier. If product was damaged in transit to you, file claim with carrier

Dayton<sup>®</sup>

N G L	
L	
L	
S	
Н	

Dayton Operating Instructions and Parts Manual				
Notes				
