

HEAVY DUTY BRASS STRAINER

1PPF4

INSTRUCTIONS:

1. Disassemble all parts from strainer body. See illustration.
2. Spread a generous amount of plumbers putty on underside of strainer flange.
3. Insert strainer body through drain hole opening in sink. Press down firmly.
4. From underside of sink, first place rubber washer and then friction washer on strainer body.
5. Screw threaded locknut onto threads of strainer body and tighten with wrench.
6. Remove excess plumbers putty.

