



Instructions for fitting RX Insert into Pyramex V2G lenses

TO REMOVE:

1. Grasp the metal insert with your thumb and forefinger and gently pull towards you.

TO INSERT:

1. Align the center piece of the RX Insert with the center bar and gently push into position.

WARNING

Pyramex RX insert lenses are designed to fit the V2G model only. Please read all warnings that accompany the V2G.

Prescription lenses in the range of +3.00D to -3.00D are recommended for this insert. Please consult your optometrist for proper fitting.

This insert has to be used as an accessory **ONLY** to the V2G. The use of this product without the V2G may result in serious personal injury, including blindness.

The eyewear without the RX insert complies with the High Impact requirements of the ANSI Z87.1-2003 standard and bears the Z87+ mark.

The use of polycarbonate RX lenses is highly recommended. Polycarbonate lenses provide a higher level of impact protection the other lens materials.