

ROUND DOME TOP UTILITY MARKER INSTALLATION GUIDE

MATERIALS

- 1 anchor tube
- 1 post

Note:

- Assembly and installation should be performed by qualified personnel only
- Always call 811 prior to digging

INSTALLATION AND ASSEMBLY:

1. Locate and dig hole 10" diameter by 18" deep. Make sure to save the dirt to backfill after the marker is installed.
2. Slide the anchor tube through pre-drilled holes near the base of post. See Figure 1.
3. Insert post into the 10" hole. Make sure the post is deep enough to meet the "bury line" decal marked on the anchor tube.
4. Backfill the hole with removed dirt and tamp thoroughly to secure the marker into the hole.



Figure 1