

RM69

Brake Tubing Reamer

**THE RIGHT
WAY TO
PREP TUBING**



Prepare Tubing For Flaring In Seconds

- Deburr 3/16", 1/4", 5/16", & 3/8" tubing
- Advanced six-flute design produces smoother, cleaner tubing
- Eliminates additional labor due to bad flares
- Reduces wear on flaring tool punches



**After cutting,
tubing needs
deburring**



**Deburred tubing is
smooth, ready for
flaring**