7ft and 13ft Wall Mounts

Parts List:











Required Tools

- 1. Determine mounting height and location on wall for Grip Connector. See Figure A.
- Make sure Grip Connector is vertical and top surface is level. Install upper 1¹/₂" Flat Head Screw. (Drywall anchors should be used if there is not solid backing in the wall. Some mounting conditions may require different hardware.)
 Complete intallation by installing lower 1¹/₂" Flat Head Screw. See Figure B.
- Slide Wall Mount Mechanism over dovetail on the Grip Connector until Grip Connector midpoint is aligned with Wall Mount Mechanism midpoint. Loosen Pan Head Screw for an easier fit. See Figure C.
- 4. Tighten Pan Head Screw to secure Mechanism. See Figure D.
- Mount Wall Receptable (sold separately)
 opposite from Wall Mount Mechanism using two
 screws supplied. Make sure receptable is level
 with belt and Wall Mount unit. See Figure E.











