

---

## How to Attach an Angle End Stop to a Conveyor

1. Check to make sure you have all the components and tools you will need for installation.
  - a. End stop
  - b. Drill
  - c. Mounting Hardware
  - d. Tools
2. In order for the angle end stop to be attached to the top of the conveyor, a 27/64" (7/16" will work also) hole will have to be drilled into the top flange of the unit. Line up where the holes need to be drilled, and check to see if you have to remove the last roller in the unit to allow room for the angle stop to be mounted.
3. Once the holes have been properly drilled, bolt the angle stop down to the unit using the provided hardware.

\*Angle end stops can be used on any unit since they attach to the top flange of the conveyor itself\*

