

INSTRUCTION SHEET

Caster Installation for Models 3848, 3842, 3548, 5860

Hardware needed for attaching casters: 3/8-16 x 1" Carriage Bolt
3/8-16 Hex Nut
3/8 Split Lock Washer

To install casters:

1. Position carriage bolts through square holes in bottom of box.
2. Mount casters from underside.
3. Put washers over bolts.
4. Thread nuts onto bolts.
5. Tighten nuts to approximately 20 foot-pounds.

