



- 1) REMOVE THE MANUFACTURE'S MOUNTING PLATE FROM THE BACK OF THE MONITOR AND SAVE THE FOUR MOUNTING SCREWS.  
(FOR 100MM HOLE TO HOLE PATTERN MONITORS, USE ADAPTOR PLATE FOR 75MM HOLE TO HOLE PATTERN MONITORS, MOUNT DIRECTLY TO "H" PLATES)
- 2) PLACE THE PRO-LINE ADAPTER PLATE OR "H" PLATES AGAINST THE PREVIOUSLY VACATED SPOT WITH THE STUDS FACING OUT. USING THE FOUR SCREWS REMOVED IN STEP ONE, SECURE THE PRO-LINE ADAPTER PLATE TO THE MONITOR.
- 3) ATTACH THE KEYBOARD MOUNTING PLATE TO THE BACKSIDE OF THE "H" PLATE USING 8/32" ACORN NUTS AND FLAT WASHERS.
- 4) ATTACH THE KEYBOARD TRAY TO THE KEYBOARD MOUNTING BRACKET USING 8/32" ACORN NUTS AND FLAT WASHERS. (4 PLACES)
- 5) TO ADJUST THE KEYBOARD TRAY HEIGHT, LOOSEN THE KNOB ON THE REAR OF THE KEYBOARD TRAY ASSEMBLY AND ADJUST TO YOUR PREFERRED HEIGHT

PRO-LINE  
ASSEMBLY OF THE  
KEYBOARD TRAY PORTION  
ON A FSMA-1  
DRAWING #A7722

GRAINGER #  
16D640