



1) INSTALL MOUNTING BRACKET (#1) AT DESIRED HEIGHT ON UPRIGHT. USING 3/8" STRUT NUTS AND BOLTS PROVIDED.  
 NOTE: BRACKET CANNOT BE MOUNTED LOWER THAN 9 1/2" ABOVE WORKSURFACE.

2) INSTALL MONITOR ARM ASSEMBLY (#2) TO MOUNTING BRACKET (#1) USING 3" BOLT (#3) AND LOCKING HANDLE (#4).

GRAINGER #'S  
 4LJ58  
 8WR98

PRO-LINE  
 MA-1 (ARTICULATING MONITOR ARM ASSY)  
 DRAWING #A7147