

# MOUNTING INSTRUCTIONS

## PARTS LIST

- A - GALVANIZED STEEL BACK PLATE
- B - STYROFOAM PAD (**NOT PICTURED**)
- C - .020" THICK ALUMINUM MIRROR
- D - POLISHED STAINLESS STEEL MIRROR FRAME

- # 1 CAREFULLY REMOVE AND SEPARATE THE PARTS FROM THE BOX.
- # 2 MOUNT THE BACK PLATE "A" TO THE WALL USING THE SCREW HOLES.
- # 3 SET THE STYROFOAM PAD ON THE THE BACK PLATE "A" THEN SET THE MIRROR "C" ON TOP OF THE STYROFOAM PAD "B" KEEPING BOTH INSIDE THE ROLLED FLANGED EDGES. **DO NOT LET MIRROR SLIP DOWN OVER THE ROLLED EDGE.** THE MIRROR MUST STAY ON TOP OF THE FLANGE.
- # 4 MOUNT "D" THE FRAME STARTING AT THE BOTTOM CENTER AND BEGIN SNAPPING IT OVER THE ROLLED FLANGE EDGES OF THE BACK PLATE.

NOTE: THE MIRROR CANNOT BE DISASSEMBLED ONCE MOUNTED.

