INSTRUCTIONS:

- 1. Remove wing nut.
- 2. Place cover through unused hole in sink.
- 3. From underside of sink, screw wing nut onto threaded bolt.
- 4. Tighten securely.