




OPERATING INSTRUCTIONS & PARTS MANUAL (OIPM) Brake kit (1ULG3/1ULN9)














Parts No.	Name	number
1	Axle	1 pc.
2	Washer	3 pc.
3	Brake Arm	1 pc.
4	Spring Washer	1 pc.
5	Brake Pad	1 pc.
6	Bushing	1 pc.
7	Lock Nut	1 pc.

- Steps:
- Remove the old long bushing and plastic washers. Insert the new bushing (6) and steel washers (2) into the wheel.
- 2. Put the wheel assembly into the caster forks.
- 3. Insert the brake pad (5) between the fork and wheel.
- 4. Keep these parts in line.
- 5. Mount other parts as the figure 5, tighten it.
- 6. Now the brake is ready for use.

NOTE: 1. Product images are shown for display purposes only and may not be representative of the final product.

2. Wheel and Caster plate are not included.

Manufactured for Grainger International, Inc. Lake Forest, IL 60045