Please read and save these instructions. Read through this owner's manual carefully before using product. Protect yourself and others by observing all safety information, warnings, and cautions. Failure to comply with instructions could result in personal injury and/or damage to product or property. Please retain instructions for future reference.



Description

This all purpose Westard utility cart is ideal for the pickup & transport of supplies, mail, parts, tools, and inventory to various locations. Bottom and top shelves ideal for bulky items. Includes 4- swivel 3" casters and powder-coated finish that prevents surface rust.

Unpacking

After unpacking unit, inspect carefully for any damage that may have occurred during transit. Check for loose, missing, or damaged parts. Shipping damage claim must be filed with carrier.



Specifications and Dimensions

			No. of	Dimensions (Inches) Surface
Model	Type	Casters	Drawers	Width Depth Height Construction
2CZY4	Standard	4 Swivel, 2 Lock	0	27 18 28 Steel

General Safety Information

A CAUTION

Use the brakes when not moving the cart. When moving this cart, do not pull it. Instead, PUSH the cart to prevent personal injury.

AWARNING

Follow the assembly instructions to assemble the cart properly. Improper assembly may cause personal injury. Do not alter the product in any manner. Do not step on the shelves or climb on the cart.






UTILITY CART

Assembly

NOTE: Finger tighten all bolts until the cart is completely assembled, then wrench tighten.

- 1. Assemble E and H using B(16), C(16), D(16)
- 2. Assemble I and H using B(16), D(16)
- 3. Assemble I and G using B(14), D(14)
- 4. Assemble J to G using A(2), D(2)







UTILITY CART

PARTS LIST

PART NAME			QUANTITY	PART	NAME	QUANTITY
Α.		M8X16 HEX BOLT	2			
В	B M8X12 HEX BOLT		46			
С	0	WASHER	16			
D		NUT 13mm	48			
Ε		CASTER 4"×1"	2			
F		CASTER W/BRAKE 4"×1"	2			
G		TOP SHELF	1			
Н		BOTTOM SHELF	1			
I		FRAME	4			
J		SIDE HANDLE	1			
					·	

Maintenance

Lubricate lock with graphite. Lubricate the ball bearing slides with grease.

For Repair Parts, call 1-800-323-0620

24 hours a day - 365 days a year

Please provide the following:

- Model Number
- Serial Number (if any)Part description and number as shown on parts list








Figure X – Repair Parts Illustration for Model(s) 2CZY4



UTILITY CART

Repair Parts List

Reference	Bernstellen	De et Nieuwik en	OTV	GIS SKU
Number	Description	Part Number	QTY	313 313
1	Side handle, power coated	02-0009	1	2CZY1, 2CZX2, 2CZX4, 2CZX9
	7.			, , , ,
				2CZX1, 2CZX3, 2CZX6, 2CZX7, 2CZX8,
1	Nameplate	76-0008	1	2CZY2, 2CZY3, 2CZY5
1	Tubular side handle	02-B003	1	2CZY4
2	Cide corriing handles abrome plated	04.005	1	20774 20772 20776 20777 20778
2	Side carrying handles, chrome-plated	04-09F	1	2CZX1, 2CZX3, 2CZX6, 2CZX7, 2CZX8
2	Nameplate	76-0008	1	2CZY1, 2CZX2, 2CZX4, 2CZY7, 2CZX9, 2CZY4
2	MDF work top	20-A05	1	2CZX5
2	Drawer trim for small drawers	F331031-3DX	1	2CZY2, 2CZY5
	Small Drawers (w/ slides & aluminum			
3	pull)	F331031-3D	1	2CZY2, 2CZY5
3	Plastic caps for side handle holes	17-14	2	2CZY1, 2CZX2, 2CZX4, 2CZX9
3	Plastic handle	04-19	1	2CZY7
4	Gas Struts	31-03A	1	2CZX3, 2CZX6, 2CZX7, 2CZX8
4	Slide-out perforated panel (w/ slides)	F270081-2	1	2CZY7
	chart car period paner (in charce)		-	
				2CZY1, 2CZX2, 2CZX4, 2CZY7, 2CZX9,
4, 5	Swivel caster with brake		1	2CZY2, 2CZY3, 2CZY4
9, 5, 4, 9	Swivel caster without brake		1	2CZY2, 2CZY3, 2CZY4, 2CZY5
5	Fixed caster		1	2CZY1, 2CZY2, 2CZX2, 2CZX4, 2CZY7, 2CZX9, 2CZY3, 2CZY4
				, ,
				2CZY1, 2CZY2, 2CZX2, 2CZX4, 2CZY7, 2CZX1, 2CZX3, 2CZX6, 2CZX7, 2CZX8,
7, 9	EVA top mat	73-454	1	2CZX9
	Large Drawers (w/ slides & aluminum			
7	pull)	F270081-4D	1	2CZY7
8	Small Drawers (w/ slides & aluminum	E270084 2D		20777
0	pull)	F270081-3D	1	2CZY7
				2CZY1, 2CZY3, 2CZY5, 2CZY2, 2CZX2, 2CZX4, 2CZY7, 2CZX1, 2CZX3, 2CZX6,
*	Draw liner	2H182	1	2CZX7, 2CZX8, 2CZX9

NOTE: (1) TO ORDER JUST KEYS OR TO MATCH LOCK TO ANOTHER UNIT, GIVE NUMBER THAT IS STAMPED ON FACE OF LOCK. (2) REPLACEMENT KEYS MAY BE ORDERED USING THE LETTER AND NUMBER COMBINATION WHICH APPEARS ON THE FACE OF THE LOCK AS THE PART NUMBER. (3) Asterick * = Not shown.

