



PIG® Grippy® Floor Mat Care and Use Guide

PIG® Grippy® Mats should be applied only to clean and dry floors. The mats should be changed out after 12 weeks of use or whenever they show signs of excessive wear or lifting from the floor. PIG® Grippy® Mat can be left in place during daily cleaning with floor scrubbers (use low settings for water and pressure), vacuums, brooms, and mops. Normal amounts of moisture will evaporate from the mats in a few hours. When excessive moisture saturates the mats due to rain, snow, or ice, accelerated drying can be achieved using a wet-vac, fans, or floor blowers. All adhesives have potential to lift finish coatings or paint depending on the condition of the surface. PIG® Grippy® Mat is formulated to work with most industrial and commercial floor surfaces but, depending on floor type, traffic volume, and conditions, some surfaces may not be suitable for PIG® Grippy® Mats. Testing a 6" square piece in a noncritical area is recommended to judge suitability for your use.