
TD - 80611 A **HUR-520**



Hurricane

Technical Data

4000psi Pressure 250°F Temperature max. 2000 rpm RPM ø20.5" Housing 3/8"NPTF Water connection Nozzle connection 2x 1/8"NPTF Throughput medium water (pH 3-12)



TD - 80611 A HUR-520



Hurricane

Indication (original language German):

- Read all instructions, check overall conditions and safety requirements before initial operation of the product.
- Our product should only be installed by experienced users of high pressure equipment.
- Safety regulations and guidelines (Accident Prevention Rules) from the manufacturer of your high pressure cleaner are applicable.
- Nozzle installation according to Nozzle manufacturer.
- Do not run the product if the rotor-arm is out of balance or bent, damage to the swivel will result.
- No modifications to the product are permitted.


<u> (Caution:</u>

- Always use protection gear when using products connected to high pressure.
- Before any maintenance or nozzle-change, turn off the high pressure water supply, e.g.: turn off and secure the power switch.
- After turning off the system, allow all selfpropelled equipment to come to a complete stop before handling. Risk of injury due the rotor-arm.
- Do not lift up the product while operating.

<u> 🧥</u> Warning:

- Never direct any high pressure water-jet at humans, animals or electric installations.
- Do not touch the rotor-arm during operation. Risk of injury.

Pressure Equipment Directive 97/23/EC Annex III. Mosmatic AG Oberhelfenschwilerstrasse 6 CH - 9126 Necker Switzerland Phone: +41 (0) 71 375 64 64
Oberhelfenschwilerstrasse 6 CH - 9126 Necker Switzerland Phone: +41 (0) 71 375 64 64
CH - 9126 Necker Switzerland Phone: +41 (0) 71 375 64 64
Switzerland Phone: +41 (0) 71 375 64 64
Phone: +41 (0) 71 375 64 64
International Communication and
Internet: www.mosmatic.com
listed below based on the conception, design and construction uct, conclusively at the time of the declaration applicable equirements of the Pressure Equipment Directive.
High Pressure Accessories
FL / DR / RDW / SPI / TYR / TYW
Pressure Equipment Directive 97/23/EC
Article 3 / Number 1.3 / Letter a) / Second dash
Article 3 / Number 1.3 / Letter b) / Second dash Fluid Group 2
Directive 97/23/EC Module H (Full Quality Assurance)
Machinery Directive 2006/42/EG
Pressure Equipment Directive 97/23/EC
ISO 12100:2011 - Safety of Machinery
ISO 9001:2008 - Quality Management System
Patrick Rieben
duct, alterations on the product or the fitting of non- the declaration of conformity with immediately effective
Signature:






Hurricane

Assembly instructions (original language German)

- 1. Dismount both wheels (4).
- 2. Install the lower fork (14) with the bolts (15) through the wheels (4) to the rack (16).
- Slide the upper fork (17) over the lower fork (14). Secure the two forks with the bolt (18) and the safety nut (19).
 Note: The handle (20) and the ring (21) must point in the same direction.
- 4. Connect the HP-gun (8) with the preinstalled adapter (7) to the quick-connect (6).



Spare parts	list
-------------	------

Pos.	Art. Nr.	Description
1	58.553	Swivel-90° (DYF)
2	36.905	Carbide seal-kit
3	50.155	Quick-Connect (M22x1.5-F / G1/4"F)
4	900.933	Rubber wheel (ø5")
5	903.325	HP-hose (G1/4"kM / G1/4"kM)
6	50.903	Quick-Connect (M22x1.5-F / G1/4"M)
7	51.275	Adapter (M22x1.5-M / G1/4"M)
8	29.081	HP-gun (4500psi)
9	1503	HP-nozzle (1503)
10	82.891	Rotor arm (ø18.5")
11	903.318	Protection ring (ø20.5")
12	900.932	Stainless steel caster (ø2.4")
13	80.621	Protective plate (ø20.5")