



**LENS REMOVAL INSTRUCTIONS**



1. Push down on one side to release lock.



2. Place fingers under rib and pull outward from center of fixture.



3. Rotate lens counterclockwise to release from rear reflector.