




54ZU85A HORIZONTAL SOAP DISPENSER



SPECIFICATIONS:

Capacity – 40 oz. (1.18L)

Material – #304 Stainless Steel

Soap Valve – ABS

Suitable for Dispensing – Liquid Soap, Detergent, Conditioner, etc.

Includes – Mounting Hardware, Key

INSTALLATION:

1. Select the desired mounting position, allowing a minimum of 6 inches between the bottom of the Dispenser and the Basin.
2. Add 4½ inches to the bottom of the dispenser to determine where the top of the Back Plate should be mounted onto the wall or secure surface.
3. Mount the Back Plate with the screws provided.
4. Slide the Soap Dispenser onto the top of the Back Plate.
5. Unlock the Lid Lock and open the Dispenser.
6. Tighten the internal screw to engage the notch of the Back Plate to engage the anti-theft feature.
7. Fill the container with the desired solution and close the lid (locks automatically).
8. Depress and release the soap valve a number of times until solution is provided.

REFILL DISPENSER:

Repeat steps #5, 7 & 8 as required.

Call or visit your local branch or go to grainger.com/toughguy for complete product line information.

©2019 W.W. Grainger, Inc. W-BUPX115-01



GRAINGER.COM® | 1.800.GRAINGER

