




AutoFoam Standard Floor Stand Assembly Instructions
Soporte de piso estándar de AutoFoam Instrucciones de ensamblaje
Socle sur plancher standard Autofoam Directives d'assemblage
AutoFoam Standard-Bodenständer Montageanleitung



2143543

Note:



- 2143543 - Accomodates all RCP AutoFoam Dispensers (Standard & LumeCel™)
- 2143543 - Admite todos los dispensadores RCP AutoFoam (Estándar y LumeCel™)
- 2143543 - Compatible avec tous les distributeurs AutoFoam de RCP (Standard et LumeCel™)
- 2143543 - Geeignet für alle RCP-AutoFoam-Spender (Standard und LumeCel™)

Included Incluido Inclus Enthalten:		
Base Base Base Basis	A	1
Backplate Placa posterior Plaque Rückplatte	B	1
Bottom Pole Poste inferior Poteau inférieur Untere Stange	C	1
Top Pole Poste superior Poteau supérieur Obere Stange	D	1
M5x50 Screw Tornillo M5x50 Vis M5x50 Schraube M5x50	E	2
M5x14 Screw Tornillo M5x14 Vis M5x14 Schraube M5x14	F	6
M5 Flange Nut Tuerca de reborde M5 Écrou à embase M5 Flanschmutter M5	G	2
M5 Locknut Tuerca de bloqueo M5 Contre-écrou M5 Sicherungsmutter M5	H	4
Allen Key Llave Allen Clé Allen Inbusschlüssel	I	1
Nut Wrench Llave de tuerca Clé à écrou Schraubenschlüssel	J	1

Not Included | No incluye | Non-inclus | Nicht enthalten:

Phillips Head Screwdriver | Destornillador Phillips | Tournevis cruciforme | Kreuzschlitzschraubenzieher
 AutoFoam Dispenser (Standard & LumeCel™) | Dispensador de AutoFoam (Estándar y LumeCel™) |
 Distributeur AutoFoam (standard et LumeCel™) | AutoFoam-Spender (Standard und LumeCel™)

Stand Assembly | Ensamblaje de la base | Ensemble de socle | Montage des Ständers



AutoFoam Dispenser Mounting
Montaje del dispensador de AutoFoam
Assemblage du distributeur AutoFoam
Anbringen des AutoFoam-Spenders

