

# Repair Parts For Use With V-9502 Pneumatic Valve Actuator Positioner


## Description

The V-9502 Pneumatic valve positioners can be reconditioned using the parts from the selection chart below.

## Selection Chart

### Repair Parts For Use With V-9502 Pneumatic Valve Actuator Positioner

Code Number	Callout	Description
<b>C-9506-1</b>	<b>A</b>	Positioner Movement Complete Less Items "B" and "C"
<b>D-9502-604</b>	<b>B</b>	Operating Span Lever Arm Assembly
Refer to Positioner Springs tables in V-9502 Series Pneumatic Valve Actuator Positioners Catalog Page (LIT-1924100) on Page 27.	<b>C</b>	Springs



**Repair Parts, V-9502**