

1



- Place a piece of bungee through the bottom of the hook and up through the front leaving 3" of spare bungee to work with to clamp off.
- Fold over the bungee one time the length of the inside of the hook and attach the clamp using the Pliers we sell that are grooved on the inside to especially fit the clamps.
- You can use regular pliers but we cannot guarantee a secure bend of the clamp.

2



- You will be able to secure the clamp around the bungee very tightly.
- Once you have secured the bungee clamp and feel that it is strong (two clamps can be used for stronger applications), pull the bungee back through the hook.
- Feed the loose clamped end into the hook.

3



- The bungee clamp with the doubled over bungee will fit tightly into the hook.
- Feed the 2 loose ends of the bungee and the clamped over end into the hole of the hook as illustrated in picture #3 above.
- Pull the bungee until the clamped end in tightly in the hook.

4



- The bungee will fit tightly and hold a strong amount of weight with this method of attachment.
- This is the most common way of attaching bungee cord to these type of cone hooks.